

Cavity Resonator Integrated Guided mode resonance Filter: Spectral & Modal Reflector

Romain Laberdesque, Olivier Gauthier-Lafaye, Henri Camon, Antoine Monmayrant, Marlène Petit, Olivier Demichel, B. Cluzel

► To cite this version:

Romain Laberdesque, Olivier Gauthier-Lafaye, Henri Camon, Antoine Monmayrant, Marlène Petit, et al.. Cavity Resonator Integrated Guided mode resonance Filter : Spectral & Modal Reflector. The 5th International Topical Meeting on Nanophotonics and Metamaterials (NANOMETA 2015), Jan 2015, Seefeld, Austria. 48, pp.1619 - 1621, 2015. hal-01931258

HAL Id: hal-01931258 https://laas.hal.science/hal-01931258v1

Submitted on 22 Nov 2018

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.

LAAS-CNRS Laboratoire d'Analyse et d'Architecture des Systèmes rontières **Cavity Resonator Integrated Guided mode resonance** Filter : Spectral & Modal Reflector Romain Laberdesque, Olivier Gauthier-Lafaye, Henri Camon, Antoine Monmayrant,

PHOTO, CNRS, LAAS, 7 avenue du Colonel Roche, F-31400 Toulouse, France, arlène Petit, Olivier Demichel, Benoît Cluzel, Optique de Champ Proche, Laboratoire Interdisciplinaire Carnot de **Bourg**ogne, <u>Université de Bourgogne, 9 avenue Alain Savary, F-21078 Dijon, France</u>

CRIGF : What is it ?

CRIGF is a new generation of narrowband filter. It consists of subwavelength gratings nearby or upon a waveguide. At the center, a small GMRF (Guided Mode Resonance Filter) or GC (Grating Coupler) coupled radiated & guided mode, then, **DBR (Distributed Bragg Reflector)** at each side localise mode inside a horizontal Fabry-Pérot cavity. Two **PS (Phase sections)** are use to fine tune the Fabry-Pérot modes with the grating coupler.





CRIGF : What is it for?

Extended Cavity Diode Lasers (where a laser diode is inserted in an optical cavity with a spectrally selective element) can benefit from CRIGFs high angular accceptance. Wavelength stabilization in small and robust cat's eye cavity have been demonstrated.



844846848Wavelength (nm) Buet, X.; Guelmami, A.; Monmayrant, A.; Calvez, S.; Tourte, C.; Lozes-Dupuy, F.; Gauthier-

Kenji Kintaka, Tatsuya Majima, Junichi Inoue, Koji Hatanaka, Junji Nishii, and Shogo Ura, "Cavity-Resonator-**Integrated Guided-mode resonance Filter** for aperture miniaturization," Opt. Express **20**, 1444-1449 (2012)

Lafaye, O., "Wavelength-stabilised external-cavity laser diode using cavity resonator integrated guided mode filter", Electronics Letters , vol.48, no.25, 1619-1621, 2012



CRIGF

Short GMRF (GC) + Modes FP

=> Phasing between GC profile & standing wave

=> Moiré Effect







