


# Spectrally-shaped illumination for improved optical inspection of lateral III-V-semiconductor oxidation

N. MONVOISIN<sup>1</sup>, E. HEMSLEY<sup>1</sup>, L. LAPLANCHE<sup>1</sup>, G. ALMUNEAU<sup>1</sup>, S. CALVEZ<sup>1</sup>, A. MONMAYRANT<sup>1</sup>

<sup>1</sup>LAAS-CNRS, Université de Toulouse, CNRS, 7 Avenue du Colonel Roche, 31400 Toulouse, France

Contacts : Antoine Monmayrant (amonmay@laas.fr) & Natan Monvoisin (nmonvoisin@laas.fr)

## Inspection of buried oxide aperture in VCSEL\* fabrication



\* VCSEL : Vertical-Cavity Surface-Emitting Laser

\*\* DBR : Distributed Bragg Reflector

### Oxide aperture in VCSELs

#### Optical confinement + Electrical confinement

Defines transverse mode distribution  
Injected current flows through the aperture

Key parameter for final VCSEL performances

Oxidation process requires  
**accurate control of aperture dimensions**

#### Optical in-situ monitoring


##### Very thin oxide layer (~30 nm) under DBR stack

Low effective refractive index contrast between unoxidized and oxidized areas


##### Oxidation process runs at high temperature (~400°C)

Degraded optical contrast due to redshifted absorption


## Spectrally-shaped source




## Shaped illumination spectrum



## Results



**Detected radius (orange line) in polar coordinate together with the confidence interval (orange area) and the average radius (black line)**



#### Spectrally-shaped illumination :

- Improves the detection of the oxide/unoxide boundary.** It combines the high flux and low noise from the panchromatic imaging with the high contrast from the monochromatic illumination.
- Is a **versatile solution** with regard to VCSEL spectral response : arbitrary tailored spectrum, temporal reconfigurability.
- Is **compatible with real-time monitoring** : embedded DMD system, synchronization DMD-camera, multiplexed reflectivity spectrum measurement (Hadamard).

N. Monvoisin et al. "Spectrally-shaped illumination for improved optical inspection of lateral III-V-semiconductor oxidation," Opt. Express (2023)

<https://doi.org/10.1364/OE.480753>



## Futur work

- Implementation of real-time monitoring.
- More advanced illumination spectrum optimization techniques : Fisher Discriminant Analysis (FDA), Principle Component Analysis (PCA).

Acknowledgements : ANR-18-ASTR-0012-01 (ImHypAd project), ANR-20-MERA-0002 (ANR M-ERANET TRAVEL project), and French RENATECH network.